

# FUTURA LAUNCH LEAD QUICK GUIDE

## CLOSING FUTURA WITH E2000 / APC CONNECTORS



While closing the lead, make sure that the **clip is oriented toward the inside** as shown in the picture



Press down the cover keeping the connectors inside